

The Old Way

OEM style is difficult to use.

Time consuming installation.

- Metal-on-metal impact.
- Temporary nut for backing wastes time.
- Inconsistent torque on the nut.
- Costly parts.

Difficult removal.

- The nut gets stuck.
- Mantles are burned.
- Heads are damaged.



Damage to the head from burning.



Unreliable and inefficient metal-on-metal impact.

Introducing a better way!
Safer – Faster – Smarter

TRI STAR
DESIGN & MANUFACTURING, INC.

Mantle Clamp™
Updated design for the
Nordberg® HP-4™

