

# The Old Way

OEM style is difficult to use.

## Time consuming installation.


- Metal-on-metal impact.
- Temporary nut for backing wastes time.
- Inconsistent torque on the nut.
- Costly parts.

## Difficult removal.

- The nut gets stuck.
- Mantles are burned.
- Heads are damaged.



Damage to the head from burning.



Unreliable and inefficient metal-on-metal impact.

Introducing a better way!  
Safer – Faster – Smarter

**TRI STAR**  
DESIGN & MANUFACTURING, INC.

**Mantle Clamp™**  
Updated design for the  
Symons® 7-ft. SH

